

Super Cooler special Instructions



Vacuum Tee installs between the intake manifold behind the throttle body and the fuel pressure regulator. The long line goes to the blow off valve

- 1 Remove the black vacuum line from the intake manifold to the fuel pressure regulator
 - 2 The end of the small hose from the supplied Vacuum Tee goes to the intake manifold
 - 3 The other small hose goes to the Fuel pressure regulator nipple
 - 4 The long hose goes to the blow off valve
- Secure all the lines with small Zip ties cut off the excess and make sure the lines do not tub against anything sharp. Wire loom helps protect them against vibration damage
- 5

